



PERSONAL PROTECTIVE EQUIPMENT (PPE)

MAXAIR CAPR® System Filters

The MAXAIR CAPR® System filter designations indicate they meet the NIOSH HE approval for PAPR filtration. Additionally, for Shroud and Hood configurations, they meet the HAPF, APF of 1000, criteria. Assigned Protection Factor (APF) means the workplace level of respiratory protection that a respirator or class of respirators is expected to provide to employees when the employer implements a continuing, effective respiratory protection program. OSHA states that all cuff configurations receive an APF of 25 protection rating. N95 respirators only carry an APF rating of 10, assuming they are fit tested and being worn properly.

The MAXAIR System provides two filter options for users depending on preference. Both offer the same level of particulate filtration, however, the 2166-10 Nuisance Organic Vapor (N-OV) Filter Cartridge is a HE filter combined with charcoal odor filtration to provide an additional level of comfort and convenience. Because the odor filtration is accomplished utilizing charcoal, it is important to place the filter in an airtight container in between uses. This will ensure the life of your odor filter to roughly thirty active days.

Note: CAPR XP Filter Cartridges do NOT filter or neutralize formalin fumes.

SPECIFICATIONS

CAPR Configuration

- DLC Lens-Cuff
- DLC Shroud
- DLC Double Shroud
- Hood, Single Shroud
- Hood, Double Shroud

NIOSH Filtration Level

- HE: ≥99.97% of airborne particles
- HE: ≥99.97% of airborne particles
- HE: ≥99.97% of airborne particles
- HE: ≥99.97% of airborne particles
- HE: ≥99.97% of airborne particles

APF

- 25 APF
- 1000 APF
- 1000 APF
- 1000 APF
- 1000 APF



www.mopec.com
 800.362.8491
 800 Tech Row
 Madison Heights, MI
 48071

Filter Ordering Options

Part ID	Description	Estimated Lifespan
2167-10	XP PLEATED FILTER CARTRIDGE (box of 3)	8-12 months
2166-10	XP N-OV FILTER CARTRIDGE (box of 3)	Particulate: 8-12 months Odor: 30 days



PERSONAL PROTECTIVE EQUIPMENT (PPE)

MAXAIR CAPR® Disposable Lens Cuffs

The MAXAIR® Systems DLC (Disposable Lens Cuff) consists of an integrated Lens and Cuff. It is the standard and basic face cover used in MAXAIR Systems PAPR configurations. **Disposable Lens Cuffs are typically the CAPR cover of choice for the majority of pathology labs, anatomy labs, and medical examiner offices.** The DLCs are NIOSH approved and provide respiratory protection against airborne particulate contaminants when properly configured and donned with a MAXAIR CAPR® Powered Air Purifying Respirator (PAPR) System.

DLCs are packaged 40 in a polybag, and one polybag of 40 in a dispensing box. The ML box is longer than the SM box so that they are easily identified and can be stacked appropriately, a SM Box on top of an ML box. The DLCs are packaged in two types of boxes, the Standard Cardboard Box and the Re-useable Plastic Box.

For more protection and comfort than an N95 mask and the full protection of a PAPR, the MaxAir CAPR System with the Lens Cuff configuration is the ideal choice.

Disposable Lens Cuff Ordering Options

Part ID	Description	Dimensions
2365-02 ML	DLC Lens-Cuff, MED/LG, cardboard box (box of 40)	18.25" x 8.75" x 2.5"
2365-02 SM	DLC Lens-Cuff, SM/MED, cardboard box (box of 40)	16" x 8.75" x 2.5"
2365RB 02ML	DLC Lens-Cuff ML plastic box (box of 40)	18.825" x 8.875" x 2.75"
2365RB 02SM	DLC Lens-Cuff SM plastic box (box of 40)	16" x 8.875" x 2.75"



www.mopec.com
800.362.8491
800 Tech Row
Madison Heights, MI
48071