

Wall-Mounted Shower and Eyewash

The wall-mounted shower and eyewash station is a critical safety feature for any workplace where hazardous chemicals, particles, or irritants may pose a risk to workers. By having these emergency systems within easy reach, you can ensure that employees can quickly and effectively rinse away contaminants from their skin and eyes, minimizing the risk of serious injury.



SPECIFICATIONS

Construction

- Completely encased in stainless steel housing
- Shower includes shower head, shower ball valve, and pull rod
- Eyewash includes eyewash assembly and hand-lever ball valve

Dimensions

- Case: 5.8" x 74.5" H
- See drawing for other dimensions

Materials

- Casing: 304 stainless steel construction with a polished No. 4 finish
- ABS plastic shower head with aluminum pull-rod
- Chrome-plated eyewash

Performance

- Shower: 20 gallons of water per minute for 15 minutes
- Eyewash: at least .4 gallons of water per minute for 15 minutes

Connections / Plumbing

- (1) 1" cold water connection, 20" above finished floor line, centered on fixture
- All plumbing lines are factory installed and tested
- Unit requires minimal hook-ups of the project location

MOPEC
GROUP

mopec
ELEVATING PATHOLOGY

MORTECH
MANUFACTURING

www.mopecgroup.com

800.362.8491

800 Tech Row, Madison Heights, MI