

# Embalming Table, Various Sizes

Designed for efficiency and durability, Mopec's Embalming Table for Trays provides a stable work surface ideal for embalming and tray-based procedures. Its corrosion-resistant stainless steel construction ensures long lasting performance, while the smooth, sloped surface promotes optimal fluid drainage. Built for mortuary and pathology environments, this table enhances workflow and reliability in daily operations.



600035-23



600035-27

## SPECIFICATIONS

### Construction

- (10) Nylon rollers to allow for smooth movement of trays on the table
- Safety latches to secure the tray in place during moving
- (2) tray rinse bars to keep fluids flowing during the embalming process
- Integrated downdraft system to pull fumes down and away from the table surface
- (4) 8" locking casters
- GFCI Duplex receptacle with waterproof cover
- Quick connections for both the rinse assembly and electrical

### Materials

- 11ga 1.5" SQ 304 Stainless steel frame with a 180-grit polished finish
- 304 Stainless steel housing with No. 4 polished finish
- (10) Nylon Rollers
- (2) Stainless steel tray rinse bars with a No. 4 polished finish
- (2) Stainless steel exhaust grills with a No. 4 polished finish

### Dimensions

- 600035-23: 80.1" L X 32.5" W X 30.9" to 32.8" H
- 600035-27: 81" L X 37" W X 36" to 38" H

### Capacity

- 500 lbs

### Compatibility

- 600035-23: For use with JC023D
- 600035-27: For use with JC027D
- Both: Only for use with the 1036-25 ventilated embalming station

### Note:

- Trays sold separately.

### Variations

Model No.	Description	Dimensions
600035-23	Embalming Table for 23" Trays	80.1" L X 32.5" W X 30.9" to 32.8" H
600035-27	Embalming Table for 27" Trays	81" L X 37" W X 36" to 38" H

**MOPEC**  
GROUP

**mopec**  
ELEVATING PATHOLOGY

**MORTECH**  
MANUFACTURING

[www.mopecgroup.com](http://www.mopecgroup.com)

800.362.8491

800 Tech Row, Madison Heights, MI