

# Nomad 360 Scene Light

The Nomad 360 Scene Light is a powerful, portable LED lighting solution designed to deliver 360° illumination for scene investigations, emergency response, and field operations. Built for durability and rapid deployment, it features an integrated tripod, telescoping height, and rugged, weatherproof construction for reliable, hands-free use indoors or outdoors.



FS456

## SPECIFICATIONS

### Construction

- Portable tripod
- 990–8,800 lumen
- Cordless
- Rechargeable Li-Ion Battery System
- Battery life of 3–24 hrs
- All-weather resistant
- Anchor strap
- D-ring
- Slide diffuser lens
- Fold out light panels

### Performance

- Can be set up in 20 seconds
- D-ring anchors the scene light as it lets a sandbag to be attached
- 3 light intensities
  - Area light: fold out light panels and slide diffuser lens up for 120° flood light
  - Spotlight: fold out light panels and slide diffuser lens down for 12° focused light
  - Scene light: fold in light panels for 360° scene lighting

### Dimensions

- Open: 39.9" x 4.6"
- Collapsed: 38.5"

### Materials

- Nylon

### Compatibility

- FS455: Nomad Carrying Bag

**MOPEC**  
GROUP

**mopec**  
ELEVATING TECHNOLOGY

**MORTECH**  
MANUFACTURING

[www.mopecgroup.com](http://www.mopecgroup.com)

800.362.8491

800 Tech Row, Madison Heights, MI