

No.2 L-Shaped Photomacrographic Scales

This L-shaped photomacrographic scale is used for accurate documentation of bite marks and patterned injuries. Made from rigid, laminated plastic, it features precise metric measurements, three crosshair circles for parallax correction, and alternating black and white bars with gray scale.



SPECIFICATIONS

Construction

- L-shaped photo scale
- 1 cm division lines
- 3 crosshair circles
- 18% grays areas
- Alternating black and white bars permit measurements from over and underexposed photographs

Dimensions

- 4" x 4" (105 mm x 105 mm)

Performance

- Used when photographing bite marks on a victim's body
- 3 crosshair circles are useful in helping to compensate for distortion resulting from oblique camera angles
- 1 cm division lines are traced and extended across the photographic print to grid an image Help with any distortion resulting from non-parallelism between the film and the object planes

Variations

Model No.	Description	Type
FT403	No.2 L-Shaped Photomacrographic Scale	Standard
FT404	No.2 L-Shaped Photomacrographic Scale	Magnetic

MOPEC
GROUP

mopec
ELEVATING TECHNOLOGY

MORTECH
MANUFACTURING

www.mopecgroup.com

800.362.8491

800 Tech Row, Madison Heights, MI